ΚΔΟΔΝΤ

DOCTORING, CLEANING, FILTRATION

CeraEdge[™] Creping Blade Safety Instructions

Quality control is 100% priority during manufacturing on all CeraEdge creping blades. Once the product reaches the customer to ensure safety and optimum performance, the CeraEdge creping blade must be handled with care.

Please Follow These Guidelines:

- Store blade inventory in dry conditions
- · Wear protective gloves when handling the blade
- Use two gloved hands when removing the blade from the packaging
- Avoid touching the unprotected coating
- Avoid carrying the blade on your own
- Depending on the blade length use a minimum of two people to carry the blade
- Do not step on the blade
- Insert blade into holder with thermal spray tip and label facing Yankee
- Install blade into holder with edge protection still intact
- Ensure blade is correctly installed and then remove edge protection before loading the blade

NOTE: Please follow your company's safety procedures whenever working with Kadant products and read all of the instructions completely before proceeding.











correctly facing the Yankee

www.kadant.com

Kadant is a global supplier of high-value, critical components and engineered systems used in process industries worldwide.